

gemini[®]

Empower Your Sound.



PARTY CASTER
(KP-800PRO)
PRO KARAOKE SPEAKER

PARTY CASTER

PORTABLE BLUETOOTH SPEAKER

Index

What's Included	2
Features	3
Product Overview	4
Introduction	7
Caution	7
Precautions	7
FCC Compliance Statement	7
Warranty and Repair	8
Limited Warranty	8
Return/Repair	8

What's Included

Please ensure that you find these accessories included with your PARTY CASTER speaker:

- (1) KP-800PRO
- (1) Wireless Microphone
- (1) Power Cable



FEATURE

Efficient clean class D amp pumping out 160 Watts of total power
All in one Karaoke/PA system, perfect for live gigs, portable use and home entertainment

High quality 8-inch bass woofer, 3-inch high frequency tweeter

Vibrant speaker lights

Bluetooth Streaming

USB input for Video playback with full controls

Separate USB record and device charge

1/8" auxiliary input

Large display for easy viewing

Two wireless microphone inputs with individual volume controls (microphones included)

T Assignable DSP effects: Digital Echo, Delay, Repeat, Reverb for vocal enhancement.

14-step Digital Key Controller to transpose the key of microphone inputs

Voice Cancel and Partner modes for canceling vocals from media.

Bass and Treble for precise audio adjustments for room tuning.

MICROPHONE

Microphone input for the included Wired microphone

CUSTOMIZABLE SOUND

Bass, Treble, and Echo control

MIXED MEDIA, TOTAL CONTROL

Built-in media player with Bluetooth streaming, FM Radio, and USB player.




DAZZLING LIGHT SHOW

Bring your party to life with LED Party lighting that dances with the music. Adjust the color and style of the lighting for the perfect effect.

SING-ALONG

Sing-along to your favorite music with the included Wired microphone.

PARTY CASTER PORTABLE BLUETOOTH SPEAKER



1. POWER

Use this button to turn the POWER ON/OFF.

2. CHANNEL GAIN VOLUME KNOBS

Use this knob to adjust the CH1,CH2,CH3,CH4 volume output

CHANNEL EFFECT ON/OFF KNOB

Press the button,button down DSP EFFECT is on, the CH1,CH2,CH3,CH4 output will with the effect when you adjust the DSP EFFECT knob.

3. MIC PAIR CONTROL

4. LINE/MIC CONTROL

5. CHANGE KEY

KEY Sharp—Press the button to change the sound quality to raise the pitch or key of the MIC/LINE input

KEY Natural—Press the button to return natural MIC/LINE input

KEY Flat—Press the button to change the sound quality to lower the pitch or key of the MIC/LINE input

6. TONE

TREBLE Knob- Use this knob to adjust the sound quality in treble range when MIC/LINE input

BASS Knob- Use this knob to adjust the sound quality in bass range when MIC/LINE input

7. LIGHT CONTROL

Light Mode- Press this button to select Light Mode

Mode 1:The light is always a different color

Mode 2:The light is stay a color,can be change color by press Light COLOR button.

Mode 3:The Light change the color to the beat of music.

Mode 4:The light is flash with a color,can be change color by press Light COLOR button.

Mode 5:The light is off.

Light COLOR- Press this button to select Light color

VOCAL CONTROL

VOCAL PARTNER- This feature in designed to work only with multiplex Karaoke music,by pressing this key the guide or lead vocal on the multiplex music will be removed when you are singing. When you stop singing the guide/lead vocal will again become audible,so it's like having a vocal partner.

VOCAL CANCEL- This feature in designed to work only with multiplex Karaoke music,by pressing this key the guide or lead vocal on the multiplex music will be removed throughout the entire song. To hear the guide/lead vocal press the key again.

8. MIC/LINE MASTER

Use this knob to adjust the master volume output

MASTER VOLUME

Use this knob to adjust the MIC/LINE MASTER volume output

9. DSP EFFECTS

ECHO Knob- Use this knob to adjust the sound quality in echo effect range when MIC/LINE input

Delay Knob - Use this knob to adjust the sound quality in delay effect range when MIC/LINE input

REPEAT Knob - Use this knob to adjust the sound quality in repeat effect range when MIC/LINE input

REBVR Knob - Use this knob to adjust the sound quality in REBVR effect range when MIC/LINE input

PARTY CASTER

PORTABLE BLUETOOTH SPEAKER

10. **USB RECORD RECORD**

RECORE—Press Record key, REC led on, start in record mode, again Press Record key, REC led OFF, record mode OFF

AUX IN

Aux output -- Unbalanced RCA connector for AUX audio output

USB/VIDEO PLAYBACK

11. **MODE**

REPEAT- Press this button to select repeat one song or auto repeat the track

MUTE- Press this button to select mute the music when USB play

PLAY/PAUSE- Press this button to play or pause the music

SKIP-: Use this button to select the previous track

SKIP+ : Use this button to select the next track

+10- Use this button to select the +10 track

12. **Source**

Press button to select BT, AUX, USB mode

Bluetooth

Short Press to enter BT Play or Pause Mode

Long Press to exits BT Paring Mode

13. **AC IN**

100V—240V 50Hz/60Hz

14. **BALANCED AUDIO OUT**

BALANCED AUDIO Outputs – XLR connectors for AUX audio output left and right output

BALANCED AUDIO Outputs – RCA connectors for AUX audio output left and right output

15. **AUX OUT**

3.5mm Aux output - Unbalanced RCA connector for AUX audio output

16. **GAIN**

AUX GAIN Knob- Use this knob to adjust AUX volume output

17. **HDMI**

USB play HDMI output

INTRODUCTION

Thank you for purchasing our KP-800PRO. We are confident that the Gemini platform of products will not only make your life easier through the use of the latest technological advancements in cross-platform connectivity and sound reproduction but will raise the bar for DJ and pro audio products. With the proper care & maintenance, your unit will likely provide years of reliable, uninterrupted service. All Gemini products are backed by a 1-year limited warranty*.

PREPARING FOR FIRST USE

Please ensure that you find these accessories included with the GSX-L2515BTB:

- (1) Power Cord
- (1) Operating Instructions
- (1) Warranty Card

PRECAUTIONS

1. All operating instructions should be read before using this equipment.
2. To reduce the risk of electrical shock, do not open the unit. There are NO USER REPLACEABLE PARTS INSIDE. Please refer servicing to a qualified Gemini Sound Products service technician. Do not attempt to return this equipment to your dealer.
3. Do not expose this unit to direct sunlight or to a heat source such as a radiator or stove.
4. This unit should be cleaned only with a damp cloth. Avoid solvents or other cleaning detergents.
5. When moving this equipment, it should be placed in its original carton and packaging. This will reduce the risk of damage during transit.
6. DO NOT EXPOSE THIS UNIT TO WATER OR HEAT.
7. DO NOT USE CLEANING PRODUCTS OR LUBRICANTS ON THE CONTROLS OR SWITCHES.

CONNECTIONS

PLEASE NOTE IT IS VERY IMPORTANT THAT YOUR AMPLIFIER HAS MATCHED POWER RATINGS! (Make sure your equipment is completely OFF and also lower ALL VOLUME, LEVEL, & GAIN controls before connecting the speaker.)

Responsible Party Name:

Innovative Concepts & Designs

Company address:

458 Florida Grove Road
Perth Amboy, NJ, 08861 USA

FCC Compliance Statement

This device complies with Part 15 of the FCC Rules. The operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC Rules. These equipment generates uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause interference to radio or television reception, which can be determined by turning the equipment off and then on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to a different outlet so that the equipment and receiver are on different branch circuits.
- Consult the dealer or an experienced radio/TV technician for help.

FCC ID: 2AE6G-KP800PRO

PARTY CASTER

PORTABLE BLUETOOTH SPEAKER

LEGALITY & SAFETY

The device is not intended for use by people (including children) with reduced physical, sensory or mental capacity. People who have not read the manual, unless they have received an explanation by someone responsible for their safety, should not use this unit. Children should be monitored to ensure that they do not play with the device. The device should always be readily accessible. The device should not be exposed to water. No objects filled with liquids, such as vases, shall be placed on the device. Always leave a minimum distance of 10 cm around the unit to ensure sufficient

ventilation. Open flame sources, such as candles, should not be placed on top of the device. The device is intended for use only in a temperate climate. At full volume, prolonged listening may damage your hearing and cause temporary or permanent deafness, hearing drone, tinnitus, or hyperacusis. Listening at high volume is not recommended. One hour per day is not recommended either. Danger of explosion if battery is incorrectly replaced or not replaced by the same type or equivalent. The battery should not be exposed to excessive heat such as sunshine or fire. Different types of batteries, or new and used batteries, should not be mixed. The battery must be installed according to its polarity. If the battery is worn, it must be removed from the product. The battery must be disposed of safely. Always use collection bins to protect the environment. The battery can only be replaced by the maker of this product, the sales department, or a qualified person. Switch the device off where the use of the device is not allowed or where there is a risk of causing interference or danger - for examples: on an aircraft, or near medical equipment, fuel, chemicals or blasting sites. Check the current laws and regulations regarding the use of this device in the areas where you drive. Do not handle the device when driving. Concentrate fully on driving. All wireless devices are susceptible to interference which may affect their performance. All our devices conform to international/national standards and regulations, and we aim to limit user exposure to electromagnetic fields. These standards and regulations were adopted after the completion of extensive scientific research. This research established no link between the use of the mobile headset and any adverse effects on health if the device is used in accordance with standard practices. Only qualified people are authorized to install or repair this product. Only use batteries, chargers and other accessories which are compatible with this equipment. Do not connect incompatible products. This equipment is not waterproof. Keep it dry. Keep your device in a safe place, out of the reach of young children. The device contains small parts which may present a choking hazard to kids.

Índice

Qué está incluido	9
Características	10
Descripción del producto	11
Introducción	14
Precaución	14
Precauciones	14
Declaración de cumplimiento de la FCC	14
Garantía y reparación	15
Garantía limitada	15
Devolución / reparación	15

Qué está incluido

Asegúrese de encontrar estos accesorios incluidos con su

PARTY CASTER altavoz:

(1) KP-800PRO

(1) Micrófono inalámbrico

(1) cable de alimentación



PARTY CASTER

PORTABLE BLUETOOTH SPEAKER

CARACTERÍSTICA

- Amplificador eficiente clase D limpio que bombea 160 vatios de potencia total
- Sistema Karaoke / PA todo en uno, perfecto para conciertos en vivo, uso portátil y entretenimiento en el hogar
- Woofer de graves de 8 pulgadas de alta calidad, tweeter de alta frecuencia de 3 pulgadas
- Luces vibrantes del altavoz
- Streaming Bluetooth
- Entrada USB para reproducción de video con controles completos
- Registro USB separado y carga del dispositivo
- Entrada auxiliar de 1/8 "
- Pantalla grande para una fácil visualización.
- Dos entradas de micrófono inalámbrico con controles de volumen individuales (micrófonos incluidos)
- Efectos DSP asignables: eco digital, retardo, repetición, reverberación para mejora vocal.
- Controlador de clave digital de 14 pasos para transponer la clave de las entradas de micrófono
- Modos de cancelación de voz y compañero para cancelar las voces de los medios.
- Graves y agudos para ajustes de audio precisos para la sintonización de la sala.

MICRÓFONO

Entrada de micrófono para el micrófono con cable incluido

SONIDO PERSONALIZABLE

Control de graves, agudos y eco

MEDIOS MIXTOS, CONTROL TOTAL




Reproductor multimedia incorporado con transmisión por Bluetooth, radio FM y reproductor USB.

Espectáculo de luces deslumbr

Dé vida a su fiesta con iluminación LED que bañan la música. Ajuste el color y el estilo de la iluminación para el efecto perfecto.

CANTAR JUNTO

Canta con tu música favorita con el micrófono con cable incluido.



PARTY CASTER

PORTABLE BLUETOOTH SPEAKER

1. PODER

Use este botón para ENCENDER / APAGAR.

2. BOTONES DE VOLUMEN DE GANANCIA DE CANAL

Controla la salida de volumen CH1, CH2, CH3, CH4

3. MANDO DE ENCENDIDO / APAGADO DE EFECTO DE CANAL

Controles CH1, CH2, CH3, CH4 Entrada DSP EFFECT / Conexión directa

4. CONTROL DE PAR MIC

5. CONTROL LINE / MIC

6. CAMBIAR CLAVE

KEY Sharp: se utiliza para aumentar el tono o la clave de la señal de entrada MIC / LINE

KEY Natural: se utiliza para devolver la señal de entrada MIC / LINE a natural

KEY Flat: se usa para bajar el tono o la tecla de la señal de entrada MIC / LINE

7. TONO

Perilla TREBLE: controla la entrada MIC / LINE DSP EFFECT signal Respuesta de frecuencia HI

Mando BASS: controla la entrada MIC / LINE DSP EFFECT señal respuesta de baja frecuencia

8. CONTROL DE LUZ

Modo de luz: USUARIO DE BLES PARA SELECCIONAR EL MODO LED RGB

Light COLOR- BLES USUARIO PARA SELECCIONAR EL COLOR RGB LED

CONTROL VOCAL

SOCIO VOCAL: esta función está diseñada para funcionar solo con música de karaoke multiplex. Al presionar esta tecla, la guía o la voz principal de la música multiplex se eliminarán cuando esté cantando. Cuando dejes de cantar, la guía / voz principal volverá a ser audible, por lo que es como tener un compañero vocal.

CANCELACIÓN DE VOCAL: esta función está diseñada para funcionar solo con música de Karaoke multiplex, al presionar esta tecla, la guía o la voz principal de la música multiplex se eliminarán a lo largo de toda la canción. Para escuchar la guía / voz principal, presione la tecla nuevamente.

9. MIC / LINE MASTER

Controla la salida del volumen maestro

VOLUMEN PRINCIPAL

Controles de salida de volumen MIC / LINE

10. EFECTOS DSP

Mando ECHO - Controles Entrada MIC / LINE Señal DSP EFFECT Salida ECHO

Perilla de retardo: controla la entrada MIC / LINE La señal DSP EFFECT altera la duración de las pausas entre las repeticiones de eco

Mando REPEAT - Controla la entrada MIC / LINE Señal DSP EFFECT Salida REPEAT

Mando REBVR - Controla la entrada MIC / LINE Señal DSP EFFECT Salida REBVR

11. GRABACIÓN USB

GRABAR

RECORE: presione la tecla Record, el led REC encendido, comience en modo de grabación, nuevamente Presione la tecla Record, led REC apagado, el modo de grabación apagado

AUX IN

Salida auxiliar: conector RCA no balanceado para salida de audio AUXUSB/VIDEO PLAYBACK

12. MODO

REPETIR

MUDO

REPRODUCIR/PAUSAR

OMITIR-

SALTAR +

+10

13. FUENTE

BT, AUX, USB

Bluetooth

Presione brevemente - Ingrese al modo de emparejamiento BT

Pulsación larga-Sale del modo BT Paring.

14. AC IN

100V—240V 50Hz/60Hz

15. SALIDA DE AUDIO EQUILIBRADA

Salidas de AUDIO BALANCEADAS - Conectores XLR para salida de audio AUX salida izquierda y derecha

Salidas de audio balanceadas: conectores RCA para salida de audio auxiliar salida izquierda y derecha

16. AUX OUT

Salida auxiliar de 3.5 mm: conector RCA no balanceado para salida de audio AUX

17. GANANCIA

Mando AUX GAIN: controla la salida de volumen AUX

18. HDMI

Salida USB HDMI play

PARTY CASTER

PORTABLE BLUETOOTH SPEAKER

INTRODUCCIÓN

Gracias por comprar nuestro KP-800PRO. Confiamos en que la plataforma de productos Gemini no solo le facilitará la vida mediante el uso de los últimos avances tecnológicos en conectividad multiplataforma y reproducción de sonido, sino que elevará el estándar para los productos de DJ y audio profesional. Con el cuidado y mantenimiento adecuados, es probable que su unidad brinde años de servicio confiable e ininterrumpido. Todos los productos Gemini están respaldados por una garantía limitada de 1 año *.

PREPARACIÓN PARA EL PRIMER USO

Asegúrese de encontrar estos accesorios incluidos con el GSX-L2515BTB:

- (1) cable de alimentación
- (1) Instrucciones de funcionamiento
- (1) Tarjeta de garantía

PRECAUCIONES

1. Todas las instrucciones de funcionamiento deben leerse antes de usar este equipo.
2. Para reducir el riesgo de descarga eléctrica, no abra la unidad. NO HAY PIEZAS REEMPLAZABLES POR EL USUARIO EN EL INTERIOR. Consulte el servicio técnico a un técnico de servicio calificado de Gemini Sound Products. No intente devolver este equipo a su distribuidor.
3. No exponga esta unidad a la luz solar directa ni a una fuente de calor como un radiador o una estufa.
4. Esta unidad debe limpiarse solo con un paño húmedo. Evite solventes u otros detergentes de limpieza.
5. Al mover este equipo, debe colocarse en su caja y embalaje originales. Esto reducirá el riesgo de daños durante el tránsito.
6. NO EXPONGA ESTA UNIDAD AL AGUA O AL CALOR.
7. NO USE PRODUCTOS DE LIMPIEZA O LUBRICANTES EN LOS CONTROLES O INTERRUPTORES.

CONEXIONES

¡TENGA EN CUENTA QUE ES MUY IMPORTANTE QUE SU AMPLIFICADOR TIENE CLASIFICACIONES DE POTENCIA IGUALES! (Asegúrese de que su equipo esté completamente APAGADO y también baje TODOS los controles de VOLUMEN, NIVEL Y GANANCIA antes de conectar el altavoz).

Responsible Party Name:

Innovative Concepts & Designs

Company address:

458 Florida Grove Road
Perth Amboy, NJ, 08861 USA

FCC Compliance Statement

This device complies with Part 15 of the FCC Rules. The operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC Rules. This equipment generates uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause interference to radio or television reception, which can be determined by turning the equipment off and then on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to a different outlet so that the equipment and receiver are on different branch circuits.
- Consult the dealer or an experienced radio/TV technician for help.

FCC ID: 2AE6G-KP800PRO

LEGALIDAD Y SEGURIDAD

El dispositivo no está diseñado para ser utilizado por personas (incluidos niños) con capacidad física, sensorial o mental reducida. Las personas que no hayan leído el manual, a menos que hayan recibido una explicación de alguien responsable de su seguridad, no deben usar esta unidad. Los niños deben ser monitoreados para asegurarse de que no jueguen con el dispositivo. El dispositivo siempre debe ser fácilmente accesible. El dispositivo no debe exponerse al agua. No se colocarán objetos llenos de líquidos, como jarrones, sobre el dispositivo. Deje siempre una distancia mínima de 10 cm alrededor de la unidad para garantizar suficiente

ventilación. Las fuentes de llamas abiertas, como las velas, no se deben colocar encima del dispositivo. El dispositivo está diseñado para usarse solo en un clima templado. A todo volumen, la escucha prolongada puede dañar su audición y causar sordera temporal o permanente, zumbido auditivo, tinnitus o hiperacusia. No se recomienda escuchar a un volumen alto. Una hora por día tampoco es recomendable. Peligro de explosión si la batería se reemplaza incorrectamente o no se reemplaza por el mismo tipo o equivalente. La batería no debe exponerse a calor excesivo como la luz solar o el fuego. No se deben mezclar diferentes tipos de baterías, o baterías nuevas y usadas. La batería debe instalarse de acuerdo con su polaridad. Si la batería está desgastada, debe retirarse del producto. La batería debe desecharse de manera segura. Utilice siempre contenedores de recolección para proteger el medio ambiente. La batería solo puede ser reemplazada por el fabricante de este producto, el departamento de ventas o una persona calificada. Apague el dispositivo donde el uso del dispositivo no esté permitido o donde exista el riesgo de causar interferencia o peligro, por ejemplo: en un avión o cerca de equipos médicos, combustible, productos químicos o sitios de explosión. Verifique las leyes y regulaciones actuales con respecto al uso de este dispositivo en las áreas donde conduce. No manipule el dispositivo mientras conduce. Concéntrese completamente en conducir. Todos los dispositivos inalámbricos son susceptibles a interferencias que pueden afectar su rendimiento. Todos nuestros dispositivos cumplen con las normas y regulaciones internacionales / nacionales, y nuestro objetivo es limitar la exposición del usuario a los campos electromagnéticos. Estas normas y reglamentos fueron adoptados después de la finalización de una extensa investigación científica. Esta investigación no estableció ningún vínculo entre el uso de los auriculares móviles y cualquier efecto adverso sobre la salud si el dispositivo se usa de acuerdo con las prácticas estándar. Solo personas calificadas están autorizadas para instalar o reparar este producto. Utilice solo baterías, cargadores y otros accesorios que sean compatibles con este

equipo. No conecte productos incompatibles. Este equipo no es resistente al agua. Manténlo seco. Mantenga su dispositivo en un lugar seguro, fuera del alcance de los niños pequeños. El dispositivo contiene piezas pequeñas que pueden presentar un peligro de asfixia para los niños.



At Gemini, our highest priority
is making your experience
unforgettable. Need help setting
up, troubleshooting, or looking
for some tips? We're here for you,
Monday through Friday 9-5PM EST.



1-844-GEMINI9



hello@geminisound.com



www.geminisound.com

**Love coupon codes and an
extended warranty?**

E-mail us a link to your product
review and we'll send you a coupon
code for our website and extend
your warranty 3 months.

US ONLY

Innovative Concepts and Design LLC
458 Florida Grove Road
Perth Amboy, NJ 08861